

PART NO DISCRIPTION

PHOTO SWITCHES



E002	A-A2KU/3AD/D015 NPN/PNP NO MS2
E003	D-A2KU/3AD/D2 NPN+PNP NO MSC

INDUCTIVE PROXIMITY SWITCHES



E148	PM3/OO/1A 1202 DC NPN/PNP NO/NC
E149	PM3/OO/2A 1204 DC NPN/PNP NO/NC



E150	PK3/OO/1A 1805 DC NPN/PNP NO/NC
E151	PK3/OO/2A 1808 DC NPN/PNP NO/NC
E152	ISM05 3010 DC NPN/PNP NO/NC

MICRO SWITCHES




E181	VS15P01C PLUNGER MICRO SWITCH
E182	VS15P02C MICRO SWITCH SHIFT LEVER
E184	VS15P04C MICRO SWITCH LONG LEVER
E186	VS15P06C MICRO SWITCH SHORT ROLLER LEVER
E187	VS15P07C MICRO SWITCH STANDARD ROLLER LEVER



E188	P-CS-71 MICRO SWITCH LOW TORQUE WIRE LEVER (PLASTIC)
------	--



E189	Z15G-1306 MICRO SWITCH PUSH BUTTON
E190	Z15G-1300 MICRO SWITCH PUSH BUTTON
E191	Z15G-1701 MICRO SWITCH LEVER
E192	Z15G-1702 MICRO SWITCH SHORT LEVER
E193	Z15G-1703 MICRO SWITCH LONG ROLLER LEVER
E194	Z15G-1704 MICRO SWITCH SHORT ROLLER LEVER
E194/4	Z15G-1744 MICRO SWITCH DOUBLE ROLLER LEVER
E195	Z15G-1305 MICRO SWITCH THIN PUSH BUTTON
E197	Z15G-1307 MICRO SWITCH EXTERNAL PUSH BUTTON
E198	Z15G-1308 MICRO SWITCH PUSH ROLLER



ACCESSORIES




E208	AA 8000 TERMINAL COVER
------	------------------------

VANDAL PROOF PUSH BUTTONS

E221	GQ22-11 1NO+1NC P/B
E221G	GQ22-1102G GREEN ILL P/B
E221R	GQ22-1102R RED ILL P/B

SAFETY SWITCHES



E321	KB NI L11 SAFETY SWITCH STRAIGHT KEY
E322	KB NI L11 SAFETY SWITCH RIGHT ANGLE KEY