


PART NO. DESCRIPTION

CONTACTORS: CL SERIES



CL-00



CL-07



G050	CL00A310T5 4KW CONTACTOR 1NO 220VAC COIL
G050/1	CL00A310T1 4KW CONTACTOR 1NO 24VAC COIL
G050/3	CL00A310T3 4KW CONTACTOR 1NO 110VAC COIL
G050/9	CL00A310T9 4KW CONTACTOR 1NO 48VAC COIL
G050/U	CL00A310T12 4KW CONTACTOR 1NO 380VAC COIL
G052	CL01A310T5 5.5KW CONTACTOR 1NO 230VAC COIL
G052/1	CL01A310T1 5.5KW CONTACTOR 1NO 24VAC COIL
G052/3	CL01A310T3 5.5KW CONTACTOR 1NO 110VAC COIL
G052/9	CL01A310T9 5.5KW CONTACTOR 1NO 48VAC COIL
G052/U	CL01A310T12 5.5KW CONTACTOR 1NO 380VAC COIL
G054	CL02A310T5 7.5KW CONTACTOR 1NO 230VAC COIL
G054/1	CL02A310T1 7.5KW CONTACTOR 1NO 24VAC COIL
G054/3	CL02A310T3 7.5KW CONTACTOR 1NO 110VAC COIL
G054/9	CL02A310T9 7.5KW CONTACTOR 1NO 48VAC COIL
G054/U	CL02A310T12 7.5KW CONTACTOR 1NO 380VAC COIL
G056	CL03A310M5 12KW CONTACTOR 1NO 230VAC COIL
G056/1	CL03A310M1 12KW CONTACTOR 1NO 24VAC COIL
G056/3	CL03A310M3 12KW CONTACTOR 1NO 110VAC COIL
G056/9	CL03A310M9 12KW CONTACTOR 1NO 48VAC COIL
G056/U	CL03A310M12 12KW CONTACTOR 1NO 380VAC COIL
G058	CL04A310M5 15KW CONTACTOR 1NO 230VAC COIL
G058/1	CL04A310M1 15KW CONTACTOR 1NO 24VAC COIL
G058/3	CL04A310M3 15KW CONTACTOR 1NO 110VAC COIL
G058/9	CL04A310M9 15KW CONTACTOR 1NO 48VAC COIL
G058/U	CL04A310M12 15KW CONTACTOR 1NO 380VAC COIL
G059	CL45A300M 18.5KW CONTACTOR
G060	CL-06 90A/50A 22KW CONTACTOR
G061	CL-07 110A/65A 30KW CONTACTOR
G062	CL-08 110A/80A 37KW CONTACTOR
G063	CL-09 140A/95A 45KW CONTACTOR
G064	CL-10 140A/110A 55KW CONTACTOR

OVERLOADS: RT SERIES

G093	RT1-J 1.8-2.7AMP OVERLOAD
G094	RT1-K 2.5-4A OVERLOAD
G095	RT1-L 4-6.3A OVERLOAD
G096	RTI-M 5.5-8 OVERLOAD
G097	RT1-N 8-12A OVERLOAD
G098	RT1-P 10-16A OVERLOAD
G099/S	RT1-S 14.5-17.5A OVERLOAD
G100	RT1-T 17-22A OVERLOAD
G102	RT1-U 21-26A OVERLOAD RELAY
G104	RT1-W 30-40A OVERLOAD RELAY