



PART NO. DESCRIPTION

OVERLOADS: RT SERIES CONTINUED



G108	RT2-D 24-32A OVERLOAD
G109	RT2-E 30-43A OVERLOAD
G110	RTA2-F 39-47A OVERLOAD



G121	RTXP SEP MOUNT FOR RT1 OVERLOAD
------	---------------------------------

CONTACTORS: ACCESSORIES – CL SERIES



G135	LB1A COIL FOR CL00-CL25
G137	LB3A COIL FOR CL03-CL45
G138	LB4A COIL FOR CL06-CL10



G148	BCLF-10 N/O CONTACT BLOCK
G149	BCLF-01 N/C CONTACT BLOCK
G150	BC LL 11 1N/O + 1N/C SIDE MOUNT



G167	BELA CL00-CL04 MECH INTERLOCK
G168	BELA02 CL00-CL10 MECH+ELEC INTERLOCK

MANUAL MOTOR STARTERS



G330	SP-330 30A MANUAL MOTOR STARTER
------	---------------------------------

G350	LG0006P1BO 200004 D.O.L
G351	BMLF START CONTACT BLOCK