

**PART NO. DESCRIPTION**

**PUSH BUTTONS AND ACCESSORIES continued**



G665 P9PDNVO LAMP HOLDER



G666 P9ACDPP PUSH ON/ PUSH OFF DEVICE



G674 P9XMN4T 4 WAY JOYSTICK



G675 P9ACFS5 ADAPTOR CLIP 5-WAY



G676 P9ARHPR HOLE PLUG



G679 P9ACRCL PADLOCK SAFETY COVER

G682 080CPT CLEAR RUBBER BOOT

G684 080CPDT CLEAR RUBBER BOOT

G692/G PBMLG 24V PILOT LIGHT GREEN

G692/R PBMLR 24V PILOT LIGHT RED

G692/Y PBMLY 24V PILOT LIGHT YELLOW

G693/G AD1602G 24V GREEN 16MM LED PILOT LIGHT

G693/R AD1602R 24V RED 16MM LED PILOT LIGHT

G693/Y AD1602Y 24V YELLOW 16MM LED

G694/G AD1623G 16MM 230V GREEN PILOT LIGHT

G694/R AD1623R 16MM 230V RED PILOT LIGHT

G694/Y AD1623Y 16MM 230V YELLOW PILOT LIGHT

G695/B PBMLL4 230VAC BLUE LED PILOT LIGHT

G695/G AD16-22DS23G 230V PILOT LIGHT GREEN

G695/R AD16-22DS23R 230V PILOT LIGHT RED

G695/W PBMLW 230VAC WHITE LED PILOT LIGHT

G695/Y PBMLY4 230V P/L YELLOW



G696 LD080324D LED CLUSTER RGA

G696/2 LD0804I LED CLUSTER 220VAC/DC



G697 080ESL BULB REMOVAL TOOL B9S



G698 BA9S LAMP FILAMENT 6-12-24V

G698/2 BA9S LAMP NEON 110-220-380V

