

PART NO DESCRIPTION

MANUAL MOTOR STARTERS



G865	SFKOI CIR 4-6.3A MANUAL MOTOR STARTER
G866	SFKOJ 6.3-10A MANUAL MOTOR STARTER
G867	SFKOK 10-16A MANUAL MOTOR STARTER

ACCESSORIES



G870	SFS05 SURFACE MOUNT ENCLOSURE
G871	SFAL11N AUXILIARY CONTACT 1NO 1NC



G874	SFBORNM UNDER VOLTAGE RELEASE
------	-------------------------------


CIRCUIT BREAKERS



G900	DG61 C06 MCB SP 6A
G901	DG61 C10 MCB SP 10A
G902	DG61 C16 MCB SP 16A
G903	DG61 C20 MCB SP 20A
G904	DG61 C25 MCB SP 25A
G905	DG61 C32 MCB SP 32A
G906	DG61 C40 MCB SP 40A
G907	DG61 C50 MCB SP 50A
G908	DG61 C63 MCB SP 63A



G918	DG62 C06 MCB DP 6A
G919	DG62 C10 MCB DP 10A
G921	DG62 C20 MCB DP 20A
G923	DG62 C32 MCB DP 32A



G927	DG63 C06 MCB TP 6A
G930	DG63 C20 MCB TP 20A



G938	DCG263/030 RCD DP 63A 30MA
------	----------------------------