

PART NO. DESCRIPTION

ANALOG INDUCTIVE SENSORS



U398	R-A1PM/XVP M12 0-10VD .3-5MM
U399	R-A3PM/XVP M30 0-10V3.5-11MM



U400	IA18ALC06AG-K
U400/3	IIA30ALC10AG-K



PNP INDUCTIVE PLUG-IN SENSORS

U401	IME08-02BPSZTOK PLUG IN 1040869
U401/1	E-AOTMZ/2AP/S1 M12 PLUG IME08-02BPSZCOS 1051205
U401/L	IME08-02BPSZTOS PNP 1040870 M8,3P,L50
U402	IA08BSN25POM5 E-MOPMZ/3AP SI40802 PLUG-IN
U402/1	E-AOPMZ/2AP/S1 12MM PLUG



U404	E-A1TMZ/3SP SI41202 PLUG-IN
U404/A	IME12-04BPSZC0K PNP NO 1040763
U404/L	PMS/OP-1H PNP C/O M12 PLUG IN
U405	PMS/OP-2H SI41204 PLUG-IN
U405/L	ICB12LN08POM1 SI41208 M12 PLG E-A1PMZ/3AP/AD

U406	E-A2TMZ/3SP SI41805 PLUG-IN PKS/OP-1H
U407	E-A2PMZ/3SP SI41808 PLUG-IN PKS/OP-2H
U407/L	E-A2PMZ/3AP/AD SI41816 PLUG IN PNP N/O

U408	E-A3TMZ/3SP SI43010 PLUG-IN
U408/A	E-A3PMZ/3SP/AD 25MM SENSING
U408/P	E-A3PMZ/3SP SI43015 PLUG-IN

NPN INDUCTIVE PLUG-IN SENSORS



U410	E-M0TMZ/3AN SI50801 PLUG IN
U414	E-M0PMZ1/3AN SI50802 PLUG-IN
U415	E-A1TMZ/3SN SI51202 PLUG IN
U416	E-M1PMZ/3SN SI51204 PLUG IN
U416/L	PMS/ON-2H 1204 C/O M12 LONG
U416/P	E-M1PMZ/3AN/AD SI51208 N/O M12 PLUG-IN
U417	E-M2TMZ/3SN SI51805 PLUG-IN
U418	E-A2PMZ/3SN SI51808 PLUG-IN
U419	E-A3TMZ/3SN SI53010 PLUG-IN
U420	E-A3PMZ/3SN SI53015 PLUG-IN